

Installation guide



Fittings for the rear parcel shelf

For most vehicle models the installation is very simple. Remove the old fitting completely and screw in the new one.

For some vehicle models, however, the thread of these new fittings is too long, in which case the thread needs to be shortened to half its size (either by sawing or sanding).

There are two ways to mount this adjusted fitting:

Method 1

Screw in the shortened fitting halfway, apply some instant adhesive glue and then immediately screw in the fitting the rest of the way.

Method 2

In this method the panel needs to be demounted. The fitting is then screwed into the panel and secured with the provided bolt. Refasten the panel and the job is done!

www.roettele-racing.de